CARVERaudio.com

A Website Devoted to the Legacy of Bob Carver's Electronics

This, and all manuals found on CARVERaudio.com have been painstakingly scanned, compiled, cataloged and archived by our <u>dedicated forum members</u>, for the benefit of all Carver audio fanatics. These manuals are NOT intended for re-sale. If you should find these manuals "For Sale" on any website, please report your findings to us, so we may have them removed.

CARVERaudio.com

CARVER

M-200t

SERVICE MANUAL

TABLE OF CONTENTS

		Page
Specifications	• • • • • • • • • • • • • • • • • • • •	I
Schematic Diagram (fold-out)		III
Part Locator (with overlay)		IV
Wiring Diagram		· v
Assembly Drawing (fold-out)		VI
List of Figures		VII
Figures		VIII
240V/110V Conversion		x
Introduction	•••••	1
The Power Supply		. 1
Triac-Controlled Transformer	•••••	1
Primary Regulator Circuit		2
Protection Circuits		3
- Over Current		3
- High Frequency	••••	. 4
- DC Offset		4
- Over Voltage		4
- Integrator		. 4
- ±12V Fault		5
Amplifier Circuits		5
Test Procedure		8
Parts List	• • • • • • • • • • • • • • • • • • • •	10

M-200t SPECIFICATIONS

```
FREQUENCY RESPONSE:
@ 3vrms lw out into 8 ohms---
20 Hz--- left channel
                       -0.1db
        right channel
200 Hz-- left channel
                        -0.0db
        right channel
                       -0.0db
2 kHz--- left channel
                        -0.0db
        right channel -0.0db
20 kHz-- left channel
                        -0.0db
        right channel
                       -0.6db
THD:
@lw out into 8 ohms---
20 Hz--- left channel
                        .015%
                        .019%
       right channel
                        .019%
2 kHz--- left channel
                       .07%
        right channel
20 kHz-- left channel
                        .15%
                       .4%
        right channel
@100w out into 8 ohms---
                        .005%
20 Hz--- left channel
        right channel
                       .03%
2 kHz--- left channel
                        .022%
        right channel
                       .04%
                        .09%
20 kHz-- left channel
        right channel
                       .17%
POWER OUTPUT:
Line @ 120 vac (held)
Into 8 ohms;
left channel only 128w
right channel only 128w
both channels driven 120w (each channel)
Into 4 ohms; (will not run with continuous rms waveform @ full power)
left channel only 203w
right channel only 205w
both channels driven 182w (each channel)
LOW VOLTAGE SUPPLY REG.:
Line @ 100vac---+12.1v
                          -12.1v
Line @ 120vac---+12.7v
Zener Dissipation--- 300mw
LINE REGULATION:
Top rail set @ 55vdc @ 120vac line
Top rail ---- 50.5v @ 100vac line
Top rail ---- 56.8v @ 140vac line
```

POWER SUPPLY THERMAL CONSIDERATION:
Top dc rail varies ± 1.0 volts with extreme temp. variations

LOW VOLTAGE FAULT:

Amp will shut down immediately if either 12 volt supply fails

DC OFFSET FAULT:

+2.2V dc will shut amp down -3.1V dc will shut amp down

LOW FREQUENCY TRIP:

Right ch. will trip @ 4Hz @ clipping
Right ch. will not trip @ 7Hz
Left ch. will trip @ 1.5Hz @ clipping
Left ch. will not trip @ 3Hz
Right and left ch. driven amp will trip @ 2Hz @ clipping
Right and left ch. driven amp will not trip @ 4Hz


HIGH FREQUENCY TRIP:
Both ch. will trip @ 30kHz before clipping

Integrator Shut-down:
trip threshold = 25V rms
trip time @ 30V rms is 40 sec. min. and 70 sec. max.


OVER VOLTAGE TRIP: 63 volts min. 67 volts max.


OVER CURRENT TRIP: should trip immediately when shorted should limit current to 9 amps


TURN OFF THUMPS --- TURN ON THUMPS should not exceed 2V peak max.




III







This manual is provided free, courtesy of CARVERaudio.com GREEN FROM (RED FROM® BLK FROM® RED FROM B ❷ WHITE FROM (A) TRANSFURM ER 2400 VOSI GREEN GREEN BLANK فسو BLANK GREEN BLACK TRANSFORMER SECONDARY WIRES Ø RED TRANSFORMER SECONDARY WIRES ORANGE TRANSFORMER SECONDARY WIRES 26 PLACES VI




DESCRIPTION OF FIGURES 1 THROUGH 8


Fig. 2 Voltage across triac at idle


Diac triggering at idle


Fig. 1

- Fig. 3 Voltage across triac at full power into 8 ohms
- Fig. 4 Voltage across C 86 when amp is into shutdown
- Fig. 5 Pos. commutator at 1 kHz full power into 8 ohms
- Fig. 6 Neg. Commutator at 1 kHz full power into 8 ohms
- Fig. 7 Positive commutator at 6 kHz full power into 8 ohms
- Fig. 8 Negative commutator at 6 kHz full power into 8 ohms
- *NOTE: All primary waveforms must be checked with a floating scope with no secondary ground reference!
- **NOTE: All commutator wave forms are measured on the collectors of the appropriate output devices.













VIII










This manual is provided free, courtesy of CARVERaudio.com



SHOCK HAZARD- DISCONNECT LINE CORD

CONVERSION FOR 120V OPERATION

- 1) LOCATE JUMPER DESIGNATION LABEL ON CIRCUIT SIDE OF PRINTED CIRCUIT BOARD 4.
- 2) REMOVE RAG PAPER COVERING JUMPERS 4 , SET ASIDE.
- 3) USING JUMPER DESIGNATION LABEL, LOCATE SPECIFIED JUMPERS ON CIRCUIT BOARD.
 REMOVE JUMPERS J2 AND J5.
- 1) INSTALL JUMPERS JI, J3, J4 AND J6. <u>CAUTION</u> INCORRECTLY REMOVED OR INSTALLED JUMPERS MAY CREATE SERIOUS SHOCK OR FIRE HAZARD!
- 5) REPLACE RAG PAPER 4, USING DOW-CORNING 732 RTV SILICONE, OR EQUIVALENT.
- 6) LOCATE FUSE HOLDER MOUNTED IN REAR PANEL € . REMOVE ABC 5 FUSE FROM FUSE HOLDER, REPLACE WITH AGC B.
- 7) REMOVE 240V LABEL AND ABC 5 FUSE LABEL FROM REAR PANEL.
- B) REPLACE TOP COVER.

CONVERSION FOR 240V OPERATION

- 1) LOCATE JUMPER DESIGNATION LABEL ON CIRCUIT SIDE OF PRINTED CIRCUIT BOARD 4.
- 2) REMOVE RAG PAPER COVERING JUMPERS . SET ASIDE.
- 3) USING JUMPER DESIGNATION LABEL, LOCATE SPECIFIED JUMPERS ON CIRCUIT BOARD. REMOVE JUMPERS 11, 13, 14 AND 10.
- 4) INSTALL JUMPERS JZ AND JS. <u>CAUTION</u> INCORRECTLY REMOVED OR INSTALLED JUMPERS MAY CREATE SERIOUS SHOCK OR FIRE HAZARD!
- 5) REPLACE RAG PAPER , USING DOW-CORNING 732 RTV SILICONE, OR EQUIVALENT.
- 6) LOCATE FUSE HOLDER MOUNTED IN REAR PANEL €. REMOVE AGC B FUSE FROM FUSE HOLDER, REPLACE WITH ABC 5.
- 7) APPLY 240V AND ABC 5 LABELS OVER VOLTAGE AND FUSE LABELS SILK SCREENED ON REAR PANEL.
- B) REPLACE TOP COVER.

00763-0

M-200t CIRCUIT DESCRIPTION

INTRODUCTION

The M-200t is a magnetic field power amplifier which utilizes unique electronic control as a substitute for large quantities of bulk copper, iron and aluminum which are required by conventional designs. This high degree of electronic control and efficiency is made possible by the M-200t's power supply, which provides power to the amplifiers on demand rather than on a constant basis. This greatly reduces power dissipation in the output devices and reduces the required size of filter capacitors, transformers and heatsinks.

THE POWER SUPPLY

The M-200t utilizes two supplies. A conventional ±12 volt "house-keeping" supply which drives the Magnetic Field regulator circuitry, the protection circuitry, and the front-end buffer amplifiers for the right and left channel amplifiers. This supply is always active as long as the M-200t is turned on, regardless of the protection circuitry or triac firing angle. The housekeeping supply uses a conventional transformer (T-1) with a split primary for 240V or 110V, 50/60 Hz operation. The power switch interrupts only the primary winding of (T-1). The triac phase control circuitry, which drives the Magnetic Field transformer (T-2), is driven by the voltage developed across one half of the split primary of (T-1). This arrangement makes it possible to maintain a constant voltage for the phase-shift network at 240V or 110V RMS of line and also provides low power switching for the main power supply (T-2). The Magnetic Field Supply provides the main amplifier supply voltages of ±25 and ±55 volts.

TRIAC CONTROLLED TRANSFORMER

Using phase controlled triac switching on the split primary of (T-2), makes it possible to obtain full control of load regulation, line regulation, and to turn the supply off during major faults.

This feature allows power to be delivered to the amplifier only as required, and provides a means of full amplifier and speaker protection without excessive or interfering circuitry being added directly in the signal path.

The firing angle of triac TR_1 , which controls the power delivered to (T-2), is determined by the variable current source of OC_1 . D_{106} , D_{107} , D_{108} , and D_{111} provide voltage "steering" for OC_1 which makes it possible to use the bi-polar device for AC control.

When the voltage on C_{86} reaches 40 volts, diac DC_1 will trigger (see fig. 1) and fire triac TR_1 , which will remain on until zero crossing and then turn off. TR_1 will remain off until DC_1 is again triggered (see fig. 2).

If sufficient current flows through OC_1 to trigger diac DC_1 before or at 90° (see fig. 3), then maximum power will be delivered to the primary of (T-2). If the current through OC_1 is insufficient to charge C_{86} to 40 volts before zero crossing, then no power will be delivered to the primary of (T-2) (see fig. 4). The normal operating range of TR_1 is demonstrated by figures 2 and 3 which indicate the minimum and maximum firing angles.

Opto-coupler OC_1 is used to provide electrical isolation between the primary and secondary circuits. The current through the LED portion of OC_1 is proportional to the power available to the primary of (T-2).

The network formed by D_{109} , D_{110} , D_{112} , D_{113} , R_{206} , R_{205} , R_{208} , and R_{212} is used to prevent hysteresis by pulling the voltage on C_{86} down after DC_1 has stopped conducting.

THE REGULATOR

Linear supply regulation is maintained by the differential amplifier formed by IC_2 pins 4, 5, and 6. This stage monitors the ± 55 volt supply rails. Since the positive supply is fed to the negative port and the negative supply to the positive port, an increase in voltage across RP_{200} and R_{218} will cause the output of the differential amplifier to go negative. This in turn will decrease OC_1 LED current and increase the charge time on C_{86} , reducing (T-2) primary voltage. The inverse will hold true if the supply rails should decrease. RP_{200} is used to adjust the secondary voltage of (T-2).

 R_{243} and D_{122} provide a stable reference voltage, other than ground, allowing the output of the differential amplifier to determine OC_1 , LED current without having to level-shift its output.

The network of D_{132} , R_{195} , and C_{75} allows the regulator to rapidly respond to decreases in positive rail voltage while slowing its response to rail voltage increase. D_{133} , R_{194} , and C_{74} perform the same function for the negative rail. This action improves the stability of the regulator.

PROTECTION CIRCUITS

Full active shutdown is provided for the following faults:

1) over current; 2) excessive high frequency; 3) D-C offset - subsonic frequency; 4) over voltage; 5) integrator shutdown; 6) ±12 volt supply failure.

All shutdown conditions (except ± 12 volt supply failures) are sensed by the comparitor formed by IC₂ pins 1, 2, and 3. Under normal operation, the reference voltage on pin 2 is 1.5 volts (divided down from the positive 55 volt rail via R₂₂₄, R₂₂₅, R₂₂₆). After shutdown has occurred, D₁₂₄ becomes forward biased and the reference voltage becomes .8 volts (divided down from the positive 12 volt supply via R₂₂₅ and R₂₂₆). When the voltage on pin 1 exceeds that on pin 2, then the output of pin 3 will go negative and forward bias D₁₂₃. This in turn will cause the output of IC₂ pin 4 to go negative which will reverse-bias the LED portion of OC₁ and turn the Magnetic Field Supply (T-2) off.

THE SHUTDOWN SENSORS OPERATE AS FOLLOWS

1) Over Current Shutdown - Operation of the positive current limiters is sensed by IC_2 pins 8, 9, and 10. Under normal operation D_1 and D_{51} are reverse biased and there is no current flow through R_{240} . With no current flowing through R_{240} , the voltage on pin 8 will be twelve volts. If limiter transistors Q_{37} or Q_7 are turned on, then current will flow through R_{240} , pulling the voltage on pin 9 below 8.4 volts. This will forward bias D_{131} and D_{127} , driving IC_2 pin 1 positive, and shut the main supply off.

*NOTE: The R.C. network of R_{234} and C_{93} , prevents false triggering and determines the sample rate of the shutdown cycle.

- 2) High Frequency Protection This feature prevents common mode conduction at the clip point at high frequencies and prevents ultrasonic oscillations from damaging speakers. Under normal operation D_{59} and D_{9} prevent the positive current limiters from turning on during negative audio excursions. Bypassing D_{59} and D_{9} with C_{54} and C_{24} allows abnormally high frequencies to turn the positive limiters on during negative excursions. This will initiate the same shutdown cycle as over-current.
- 3) DC Offset Subsonic Frequency Protection The output of the right and left channels is summed via R₂₃₂ and R₂₃₃. These resistors have different values so that shutdown will occur even if right and left channels offset in opposite directions at the same potential (i.e. R.Ch. +6, L.Ch. -6). C₉₄ rolls off all audio frequencies and allows only DC offset or subsonic frequencies to reach the shut-down sensor. DC offset is sensed by IC₂ pins 12, 13, and 14. A positive .6 volt reference on pin 14 holds the output of the comparitor at -10.4 volts during normal operation. Negative offset will pull pin 14 low via D₁₂₉ and positive offset will drive pin 13 positive via D₁₃₀. Either condition will drive pin 12 positive, forward biasing D₁₂₈ and D₁₂₇, driving IC₂ pin 1 positive, and turn the main supply off.
- 4) Over-voltage Protection Since (T-2) secondary voltage is determined by an active regulator, it is necessary to protect supply capacitors and amplifier circuitry against regulation failure. The comparator formed by IC_2 pins 12, 13, and 14 samples a portion of the positive 55 volt supply which has been divided down by R_{244} , R_{239} , and R_{243} . C_{95} prevents transient or false triggering. If the voltage on pin 13 exceeds the .6 volt reference voltage on pin 14, then pin 12 will go positive, forward biasing D_{128} and D_{127} , and drive IC_2 pin 1 positive, turning the main supply off.
- 5) Integrator Shutdown Protection The output of the right and left channels is summed and rectified by D₁₂₆ and D₁₂₅. This voltage is integrated by the R.C. network formed by C₉₇, R₂₂₈, C₉₂, and R₂₂₇. If the long term power output exceeds 78 watts (25 VRMS) for an excessive period of time, then abnormally low dynamic content and/or excessive clipping are indicated. Both of these conditions are very hard on speaker systems. If the power level fails to drop below 78 watts

This manual is provided free, courtesy of CARVERaudio.com over a reasonable length of time, then IC₂ pin 1 will exceed the 1.5 volt reference on pin 2 and turn the main supply off. When pin 1 drops below the standby reference of .8 volts, then the amp will restart.

6) ±12 Volt Supply Failure Protection - All of the shutdown modes that have been discussed so far have depended on the correct operation of comparators that require a ±12 volt supply. Therefore it is necessary to provide a means of turning (T-2) off during ±12 volt supply failures that are independent of the operation of the analog logic formed by IC₂.

Positive 12 volt supply failure protection is achieved by the network formed by R_{198} , R_{199} , and D_{134} . During normal operation D_{134} is reverse biased and the network has no effect on regulation. If, however, the positive 12 volt supply should fail, then D_{134} is forward biased, which in turn will reverse bias OC_1 LED and turn (T-2) off.

If the -12 volt supply should fail, then IC_2 pin 4 will go positive. This will forward bias D_{135} and claim the voltage on OC_1 pin 1 at positive .6 volts. Since the negative 12 volt supply is absent, OC_1 pin 2 is about zero volts. This condition limits the current through the OC_1 LED and turns (T-2) off.

Although the supply tracking transistors or commutators are actually part of the power supply, they will be discussed in the amplifier section as their operation is closely related to the audio signal.

AMPLIFIER CIRCUITS

For this discussion we will be looking at the non-inverting left channel with mention of the inverting right channel only when specific differences apply. Each channel of the M-200t uses one half of a TL072 operational amplifier as an input buffer for low noise and distortion. The right channel input feeds an inverting or negative port, and the left channel input feeds a noninverting or positive port.

The output of the left channel input buffer drives a pair of DC level shifters, Q_2 and Q_5 , which reference the audio to the two top DC supply rails. These two devices also operate as a current source which provides the DC biasing current necessary to operate subsequent stages in a low distortion class AB configuration.

The output of the DC level shifter drives a class AB common emitter stage (Q and Q $_6$) which provides the necessary voltage gain and pre-driver current.

This manual is provided free, courtesy of CARVERaudio.com

The bias network of \mathbf{Q}_3 and \mathbf{Q}_4 has two basic functions. Being located between the base of driver \mathbf{Q}_{11} and the base of driver \mathbf{Q}_{15} , it sets up the VBE of the drivers and outputs (\mathbf{Q}_{12} and \mathbf{Q}_{14}). This determines the DC idle current through the outputs. The idle current is adjusted with RP $_1$ (RP $_{100}$ in the right channel). \mathbf{Q}_3 is mounted on the heatsink and provides thermal feedback to prevent output current drift with temperature change. \mathbf{D}_3 and \mathbf{D}_4 track local ambient temperature change to improve the stability of the stage.

The pre-drive stage of Q_1 and Q_6 provides full output swing to drivers Q_{11} and Q_{15} . This driver stage provides the necessary current gain to drive the output devices Q_{12} and Q_{14} , which in turn provide full voltage swing and current to the load.

 ${\rm Q}_{13}$ is located between the bases of output devices ${\rm Q}_{12}$ and ${\rm Q}_{14}$. Its purpose is to help prevent common mode conduction and to decrease the turn-off time of the output devices. It operates by lowering its impedance as the difference between the two bases increase.

The current through the outputs is monitored by sampling the voltage drop across emitter resistors R_{47} and R_{48} . We will look at only the positive limiter circuit. As the current through \mathbf{Q}_{12} increases, the voltage across \mathbf{R}_{47} also increases. The emitter-base junction of limiter transistor \mathbf{Q}_7 is located across this resistor and when the voltage drop reaches about .9 volts, \mathbf{Q}_7 begins to conduct and diverts current away from the base of driver \mathbf{Q}_{11} . \mathbf{D}_8 allows only the positive signal component to be fed to limiter transistor \mathbf{Q}_7 . When \mathbf{Q}_7 conducts, \mathbf{D}_1 is forward biased and sends a trip signal to the over current shutdown sensor.

Normally, outputs Q_{12} and Q_{14} operate off of a ±25V supply, however this rail voltage may be increased to ±55V on demand. Commutation transistors Q_{10} and Q_{16} allow the supply voltage to "track" the audio between ±25 and ±55 volts. We will look at only the positive commutator circuit. The output signal of the amplifier is bootstrapped via C_3 and D_5 to the base of Q_9 which provides the necessary current gain for commutator Q_{10} . D_5 sets up a constant bootstrap voltage and determines the amount of lead voltage the commutator has over the output signal (see fig. 5 and fig. 6). The network formed by C_{17} , D_2 , and R_5 blocks the bias voltage on the base of Q_9 from the bootstrap network and provides additional voltage lead at higher frequencies (see fig. 7 and fig. 8).

This manual is provided free, courtesy of CARVERaudio.com

MISCELLANEOUS

 D_{20} , R_{31} , and C_{13} filter supply noise from the +55 volt supply to reduce noise in the predrivers.

The output pole of ${\rm C}_{12}$ and ${\rm R}_{53}$ operates as an ultra-sonic output filter and phase compensator.

Overall negative feedback is provided to the negative port of the input buffer via R_{18} . The amount of feedback is determined by R_{18} , R_{65} , C_{21} and R_{64} . In the right channel the feedback is determined by R_{98} , R_{153} , C_{51} , R_{152} , and R_{147} .

The front panel of the M-200t has a power on/off switch, a power indicator LED and a fault LED which indicates when the supply i into protection.

The amplifier may be operated in stereo or bridged for mono operation, with no special adaptor. Minimum recommended impedance of 4 ohms nominal for stereo and 8 ohms nominal for bridged mode.

The amplifier is protected with an eight amp AGC fuse and 70°C thermal breaker both in series with the line.

M-200t TEST PROCEDURE

- I. INSPECT AMP FOR GROSS WIRING ERRORS AND POOR SOLDER ON PCB.
- SET RP1 AND RP100 BIAS CONTROLS FOR MINIMUM IDLE CURRENT. SET RP200 FOR MINIMUM SECONDARY VOLTAGE.
- BRING VARIAC UP SLOWLY UNTIL TRIAC FIRES (approximately 87V line).
 POWER LED WILL LIGHT.
 - A) Check for excessive current draw.
 - B) Make sure both channels pass a signal (IV rms).
 - C) Rails should be about (±25, ±9.5, ±11.5).
- 4. INCREASE LINE TO 120V AC.
 - A) Check for excessive current draw.
 - B) Fault LED should be off.
 - C) Both channels pass a clean 2 kHz, IV rms signal with small crossover notch.
 - D) Rails should be about (± 30 , ± 11 , ± 12.5).
- 5. SET TOP DC RAIL TO ±56.0V (middle rail should be approximately ±25V).
- 6. ADJUST IDLE CURRENT.
 - A) Adjust RP1 for (3.0 mV " \pm 0.5 mV" across R47) with loads out. This will set the left channel (idle current at 25 \longrightarrow 35 mA).
 - B) Repeat step "A" for RP100 on right channel. Measure across R137.
 - C) Engage loads.
- 7. CHECK TRIAC FIRING FOR GOOD SYMMETRY. [Fig. 2]
- 8. CHECK BOTH CHANNELS @ 1 kHz FULL POWER @ 3V rms (128W) @ 120V line.
 - A) Verify symmetrical clipping.
 - B) Check commutators [Fig. 5 & 6].
 - C) Check distortion (.05% A-weighted) @ 2 kHz full power.
- 9. CHECK POWER BAND-WIDTH (@ full 120V line).
 - A) Verify 32V rms @ 20 Hz for 4 sec. without taking fuse.
 - B) Verify 32V rms @ 20 kHz.

This manual is provided free, courtesy of CARVERaudio.com
M-200t TEST PROCEDURE

10. CHECK HIGH-FREQUENCY TRIP

- A) Check both channels independently.
- B) Trips into clipping @ 20 kHz.
- C) Trips before clipping @ 30 kHz (25V → 26V).

11. CHECK LOW-FREQUENCY TRIP

- A) Check both channels independently.
- B) Right channel should trip @ (4 Hz @ the clip point). Right channel (should not trip @ 7 Hz).
- C) Left channel should trip @ (2 Hz @ the clip point). Left channel should not trip @ 4 Hz.
- D) If generator will not operate @ low frequencies, then 3 -6V dc may be used @ the input.

12. OVER CURRENT TRIP

- A) Drive both channels @ 1 kHz approximately 20V rms.
- B) Short left channel and observe shutdown.
- C) Short right channel and observe shutdown.

13. INTEGRATOR SHUTDOWN

- A) Drive both channels @ 6 kHz, 32 rms.
- B) Check commutators [Figs. 7 & 8].
- C) Verify shutdown in approximately 50 sec.
- D) Engage 20 dB SW and verify restart in approximately 20 sec (± 20%).
- E) *Release -20 dB SW.

14. FREQUENCY RESPONSE

- A) Drive both channels @ a +20 dBm ref. @ 2 kHz.
- B) Left channel (-0.2 dB @ 20 Hz), (-0.2 dB @ 30 kHz).
- C) Right channel (-0.2 dB @ 20 Hz), (-0.5 dB @ 20 kHz).
- D) Both channels should be within 0.5 dB of each other @ 2 kHz.

15. NOISE

- A) Shorted input should be less than 0.8 mV.
- 16. CHECK OVER VOLTAGE TRIP
 - A) Approximately 65V ±2V on top dc rail.
 - B) Be sure to reset rail to 56.0 after test.
- 17. CHECK TURN-OFF THUMPS (1V rms output into 8 ohms)
 - A) Left channel ±2V peak.
 - B) Right channel ±2V peak.

PARTS LIST

PART	ASSY DESCRIPTION
601-00176-00	ASSEMBLY, PCB M-200 110V
201-00002-00	CAP CERAMIC DISC 10PF 10% 1000V
201-00004-00	CAP CERAMIC DISC 22PF 10% 1000V
201-00010-00	CAP CERAMIC DISC 75PF 10% 1000V
201-00012-00	CAP CER DISC 100PF 10% 1000V
201-00015-00	CAP CER DISC 150PF 10% 1000V
201-00022-00	CAP CER DISC 390PF 10% 1000V
201-00027-00	CAP CER DISC 750PF 10% 1000V
201-00028-00	CAP CER DISC 820PF 10% 1000V
201-00035-00	CAP CER DISC .01UF 125V UL APR
204-00003-00	CAP MYLAR .001UF
204-00007-00	CAP MYLAR .0022UF
204-00015-00	CAP MYLAR .Oluf -
204-00017-00	CAP MYLAR .015UF
204-00026-00	CAP MYLAR .082UF
205-00001-00	CAP ELECTROLYTIC 1UF 50V RAD
205-00005-00	A CAP LYTIC 4.7UF 35V RADIAL
205-00008-00	CAP LYTIC 4.7UF 63V RADIAL
205-00010-00	CAP LYTIC 10UF 35V RADIAL
205-00012-00	CAP LYTIC 22UF 35V RADIAL
205-00015-00	CAP LYTIC 100UF 10V RADIAL
205-00019-00	CAP LYTIC 470UF 6.3V RADIAL
205-00027-00	CAP LYTIC 2200UF 25V RADIAL
205-00032-00	CAP ELECTROLYTIC 1UF 63V RAD
205-00035-00	CAP LYTIC 100UF 6.3V RADIAL
205-00036-00	CAP LYTIC 470UF 25V RADIAL

PART	ASSY DESCRIPTION
207-10003-00	CAP MET POLY .1UF 250V 20% RAD
251-00008-00	RES CFILM 2.7 OHM 1/4W PREP .4
251-00014-00	RES CFILM 4.7 OHM 1/4W PREP .4
251-00027-00	RES CFILM 16 OHM 1/4W PREP .4
251-00029-00	RES CFILM 20 OHM 1/4W PREP .4
251-00037-00	RES CFILM 43 OHM 1/4W PREP .4
251-00040-00	RES CFILM 56 OHM 1/4W PREP .4
251-00046-00	RES CFILM 100 OHM 1/4W PREP .4
251-00052-00	RES CFILM 180 OHM 1/4W PREP .4
251-00060-00	RES CFILM 390 OHM 1/4W PREP .4
251-00061-00	RES CFILM 430 OHM 1/4W PREP .4
251-00062-00	RES CFILM 470 OHM 1/4W PREP .4
251-00063-00	RES CFILM 510 OHM 1/4W PREP .4
251-00065-00	RES CFILM 620 OHM 1/4W PREP .4
251-00067-00	RES CFILM 750 OHM 1/4W PREP .4
251-00069-00	RES CFILM 910 OHM 1/4W PREP .4
251-00070-00	A RES CFILM 1 K 1/4W PREP .4
251-00074-00	RES CFILM 1.5 K 1/4W PREP .4
251-00077-00	RES CFILM 2 K 1/4W PREP .4
251-00080-00	RES CFILM 2.7 K 1/4W PREP .4
251-00081-00	RES CFILM 3 K 1/4W PREP .4
251-00082-00	RES CFILM 3.3 K 1/4W PREP .4
251-00083-00	RES CFILM 3.6 K 1/4W PREP .4
251-00084-01	RES CFILM 3.9 K 1/4W PREP .5
251-00086-00	A RES CFILM 4.7 K 1/4W PREP .4
251-00087-00	A RES CFILM 4.1 K 1/4W PREP .4

PART	ASSY DESCRIPTION
251-00089-00	RES CFILM 6.2 K 1/4W PREP .4
251-00090-00	RES CFILM 6.8 K 1/4W PREP .4
251-00092-00	RES CFILM 8.2 K 1/4W PREP .4
251-00093-00	RES CFILM 9.1 K 1/4W PREP .4
251-00094-00	RES CFILM 10 K 1/4W PREP .4
251-00097-00	RES CFILM 13 K 1/4W PREP .4
251-00098-00	RES CFILM 15 K 1/4W PREP .4
251-00100-00	RES CFILM 18 K 1/4W PREP .4
251-00101-00	A RES CFILM 20 K 1/4W PREP .4
251-00102-00	A RES CFILM 22 K 1/4W PREP .4
251-00105-00	RES CFILM 30 K 1/4W PREP .4
251-00108-00	RES CFILM 39 K 1/4W PREP .4.
251-00109-00	RES CFILM 43 K 1/4W PREP .4
251-00112-00	RES CFILM 56 K 1/4W PREP .4
251-00116-00	RES CFILM 82 K 1/4W PREP .4
251-00118-00	RES CFILM 100 K 1/4W PREP .4
251-00122-00	RES CFILM 150 K 1/4W PREP .4
251-00126-00	RES CFILM 220 K 1/4W PREP .4
251-00130-00	RES CFILM 330 K 1/4W PREP .4
251-00135-00	RES CFILM 510 K 1/4W PREP .4
251-00144-00	RES CFILM 1.2 M 1/4W PREP .4
251-00145-00	RES CFILM 1.3 M 1/4W PREP .4
251-10039-00	RES CFILM 51 OHM 1/2W PREP .5
251-10156-00	RES CFILM 3.9 M 1/2W PREP .5
252-00412-00	RES CFILM 19.1K 1/4W 1% PREP .4
253-20001-00	RES WIRE WOUND .1 OHM 2W

PART	ASSY DESCRIPTION
255-10118-00	RES MET OXIDE 3.9 K 1W
255-10129-00	RES MET OXIDE 11 K 1W
255-10131-00	RES MET OXIDE 13 K 1W
259-20001-00	TRIM POT 1 K PCB MOUNT
259-20003-00	TRIM POT 5 K PCB MOUNT
319-00001-00	DIAC 40V 1/8 WATT
320-20001-00	A DIODE PIV 75V 700 MA PREP
320-20004-00	A DIODE PIV 400V 1 AMP PREP
320-20005-03	DIODE PIV 400V 3 AMP UNPREP
320-20006-00	A DIODE PIV 400V 700 MA PREP
320-20007-03	DIODE PIV 200 FRT 3 AMP UNPREP
320-30001-00	DIODE ZENER 12V 1 WATT PREP
320-30004-00	DIODE ZENER 6.8V 1 WATT PREP
320-30005-00	DIODE ZENER 7.5V 1 WATT PREP
321-20000-00	XISTOR 202 NPN POWER MPS UO4
321-20002-00	XISTOR 202 PNP POWER MPS U60
321-40000-00	XISTOR TO92 NPN SM SG MPS 8097
321-40001-00	XISTOR TO92 NPN SM SG MPS A43
321-40003-00	XISTOR TO92 PMP SM SG MPS 8093
321-40004-00	XISTOR TO92 PMP SM SG MPS A93
321-60000-00	XISTOR TO220 NPN POWER MJE3055
321-60001-00	XISTOR TO220 NPN POWER FT317B
321-60002-00	XISTOR TO220 PMP POWER MJE2955
321-60003-00	XISTOR TO220 PMP POWER FT417B
330-30001-00	IC DUAL OP AMP BIFET (TL072)
330-30003-00	A IC QUAD OP AMP (4136)

PART	ASSY DESCRIPTION
330-40002-00	OPTOISOLATOR PHOTOTRANS.MCT275
501-00176-00	PCB MAIN M-200
602-00176-00	ASSEMBLY, TU M-200 110V
319-00050-00	TRIAC TO220 15 AMP 200 V
320-40001-00	A LED, RED
511-00002-00	HEATSINK TRIAC FAB M-200
601-00176-00	A ASSEMBLY, PCB M-200 110V
617-10007-00	TRANSFORMER 110V C-9
604-00081-00	ASSEMBLY, FINAL M-200 110V
101-30001-00	BUMPONS, RUBBER ROUND MEDIUM
105-40002-00	FUSEHOLDER PANEL MNT DOMESTIC
106-30002-00	GROMMET, GUM
108-00001-00	INSULATOR MICA TO3
109-10002-00	PHONO JACK DUAL PC MOUNT
111-20051-00	SOLDER LUG #6
118-50002-00	TRANSISTOR SOCKET TO3 PCB MNT
118-90005-00	STRN RE MCT.100 WS.15X.28 18/2
119-20004-00	TERMINAL STRIP, SPEAKER 4 POS.
159-50001-00	A TYRAP 3 3/8"L WHT
204-00030-00	CAP MYLAR .22UF
205-00031-00	CAP FILTER (LYTIC) 6000/60V
253-20025-00	RES WIRE WOUND 2.7 OHM 2W
315-10509-00	FUSE AGC 8
318-50001-00	SWITCH THERMAL 70 DEG C
321-30003-00	XISTOR TO3 NPN POWER C 4000
321-30007-00	XISTOR TO3 PNP POWER C 5000
321-50000-00	XISTOR TO98 W/TAP SM SG 2N3403

PART	ASSY DESCRIPTION	
401-90001-00	LINECORD 18 GAGE 2 WIRE SPT	2
507-00007-00	BRACKET, 6000UF 60V CAP MNT, F	ΆB
511-00003-00	HEATSINK TRANSISTOR FAB M-20	10
617-10009-00	TRANSFORMER 110V M-200T	
607-00081-00	ASSY, BUTTON UP M-200 GRAY 1	10V
318-20001-00	SWITCH ROCKER SPDT BLK	
503-40006-01	A PANEL FRONT SCREEN M-200 GRA	Υ.
504-20009-01	A COVER TOP PAINT BLK M-200	•
512-00202-03	STANDOFF 1/40DX.109IDX2 1/8N	YL
532-20012-00	BOX M-200	
532-30009-00	FOAM END BLOCK (M-200)	
990-00003-00	CAR, WARRANTY REGISTRATION	
990-00004-00	CARD, LIMITED WARRANTY	
990-20010-00	MANUAL M-200	